

Sears, Roebuck and Co., Hoffman Estates, IL 60179 U.S.A.
Visit our Craftsman website: www.sears.com/craftsman

File Name: Craftsman garage door manuals.pdf

Size: 4316 KB

Type: PDF, ePub, eBook

Category: Book

Uploaded: 4 May 2019, 13:42 PM

Rating: 4.6/5 from 780 votes.

Download Now!

Please check the box below to proceed.




I'm not a robot



reCAPTCHA
Privacy - Terms

Book Descriptions:

Craftsman garage door manuals



You can unsubscribe at any time. You can unsubscribe at any time. Download the FREE Craftsman Smart Garage Door Opener app Craftsman Smart Garage Door Opener. If you do not find what you're looking for on this page, please call our customer service team for prompt answers to your question. With quality at the forefront of every new product, that's why we offer choices for every line of work. Follow us as we journey across America introducing new products and opening new markets. You can unsubscribe at any time. You can unsubscribe at any time. Fasten the manual near the garage door after installation. User Ratings. Minimum Rating. Download 240 Craftsman Garage Door Opener PDF manuals. Craftsman; Garage Door Opener; Craftsman Garage Door Opener manuals. User Manual. G. Craftsman 54990 Garage Door Opener. Easy to install and maintain with a simple user interface and quick install rail system. The garage door opener will not close from a remote. Backyards Craftsman Garage Door Opener User Guide 4853a1076ea6 Owners Manual 1 2 Download and Read Craftsman Garage Door Opener Manual Craftsman Garage Door. Garage Door Opener; Craftsman; Household Appliance Craftsman; Get Craftsman 139.18453D Garage Door Opener User Manual. Garage Door Opener Users Manual 1; 2; 3; 4; 5; 6; 7; 8; 9; 10; Garage Door Opener Manual. Sears Craftsman. Download and Read Sears Craftsman 315 Garage Door Opener Manual Sears Craftsman 315. 2016 garage profile dishwasher user manual what is bcg vaccine al. Craftsman Snowblower 53881851 Manual; Craftsman Garage HP Door Opener. PDF, manuals, free download, user guide, manual, craftsman, garage, door, opener, user39s, manual. Download and Read Craftsman Garage Door Opener 41a4315 7d User Manual Craftsman Garage Door Opener 41a4315 7d User Manual Sears Craftsman Garage Door Opener Users. Sears Craftsman 53990 Owners Manual. Sears Craftsman. Sears does not seem to list manuals for their garage door opener. Download and Read Craftsman Garage Door Opener Manual Craftsman Garage Door. <http://www.tierarzt-vs.de/userfiles/focusing-manually.xml>

- **craftsman garage door manuals download, craftsman garage door manuals online,**

craftsman garage door opener manual 1 2 hp, craftsman garage door opener manual 139.539, craftsman garage door manual 1 2 hp, craftsman garage door manual release, craftsman garage door manual pdf, craftsman garage door manual lock, craftsman garage door troubleshooting, craftsman garage door installation, 1.0, craftsman garage door manuals download, craftsman garage door manuals online, craftsman garage door opener manual 1 2 hp, craftsman garage door opener manual 139.539, craftsman garage door manual 1 2 hp, craftsman garage door manual release, craftsman garage door manual pdf, craftsman garage door manual lock, craftsman garage door troubleshooting, craftsman garage door installation.

Owner's Manual


Model No.
139.53974SRT

For Residential Use Only

Caution:
Read and follow all safety rules and operating instructions before first use of this product.

Fasten the manual near the garage door after installation.

Complies with UL 325 regulations effective January 1, 1993



CRAFTSMAN


GARAGE DOOR OPENER
1/2 HP

- Safety Precautions
- Assembly
- Installation
- Adjustment
- Care and Maintenance
- Operation
- Troubleshooting
- Parts List

Sears, Roebuck and Co., Hoffman Estates, IL 60179 U.S.A.
 Visit our Craftsman website: www.sears.com/craftsman

Title Liftmaster Garage Door Opener Manual. Inc garage door opener manual, also provide craftsman. Fasten the manual near the garage door after. This garage door opener has been designed and tested to offer. 13953637srt garage door opener user manual. Craftsman 139.53515sr i 2hp user manual. Download and Read Craftsman Garage Door Opener User Manual Craftsman Garage Door Opener User Manual craftsman garage door opener user manual. Title craftsman garage door opener user manual by Kan Sakae Author Kan Sakae Subject craftsman garage door opener user manual Keywords download craftsman garage. Reload to refresh your session. Reload to refresh your session. Periodic checks of the op ener are required to ensure safe operation. DO NOT install on a onepiece door. Guardar este manual cerca de la puerta de la cochera. Se deben realizar revi siones periodicas del abridor de puertas para asegurar su operacion segura. Los dispositivos y funciones automaticas deben usarse UNICAMENTE con puertas seccionales. Installation hardware The door should stay at the point under proper sp ring tension. Ensure the end segment has trolley stop bolt facin g up. Make sure the rails are securely joined together as shown. 3. Slide the trolley onto the rail from the header segment. Make sure the arrow is poi nting towards the door as sho wn in Fig.1. 4. Connect the rail assembly to the rail bracket on the opener. To Assemble the Header Section of Rail Follow steps shown in Fig. 2 1. Remove the "trolley shaft and cable " from the chain carton and lay it beside the rail assembly. Rotate the pulley to ensure it spins smoothly. Refer to Fig.3 to connect the trolle y shaft to the trolley. Slide both the trolley shaft and trolley towa rds each

other. A “click” will be heard when they are connected. To Link Cable with Chain Refer to Fig.4. Place the chain ca rton beside the rail, hold the “chain to cable connector” and pull about 8” 20cm of chain from the box.http://www.vinaconexmec.vn/uploads/news_file/focus-user-manual-pdf.xml




Sears, Roebuck and Co., Hoffman Estates, IL 60179 U.S.A.
Visit our Craftsman website: www.sears.com/craftsman

Thread the chain to cable connector onto the trolley shaft so that they are loosely linked together. Fig.1 Fig.2 Fig.4 Fig.3 ! CAUTION DO NOT connect power until instructed. To prevent INJURY, keep hands and fingers away from joints and possible sharp edges. Wear gloves when installing chain and cable. Rail Bracket 1 3 4 2 Trolley Shaft Trolley Shaft Trolley Cable Eyelet Loosely link together Trolley Shaft Chain to Cable Connector Chain When connecting the rails ensure they are securely connected as shown above. Rail — Header Segment Rail — Middle Segments tapered x 3 Rail — End Segment tapered with Trolley Stop Bolt DOOR If the supplied chain and rails are not long enough for your installation, you may purchase an 8 foot or 10 foot Chain Drive Extension Kit. To purchase a kit, visit a Craftsman outlet, call 18883314569, or go online to www.craftsman.com Place this segment in the approximate location on the sprocket as shown in Fig.1. 3. When the chain is aligned properly around the sprocket, pull the chain to cable connector towards the trolley shaft. Compare with the illustration below. 3. Tighten the flange nut on trolley shaft against the chain to cable connector. When the chain and cable are tightened around the rail and sprocket on the opener, check and make sure the chain is properly aligned and not twisted. Attach the sprocket cover to the opener as shown in Fig.3. Notice During operation, it is normal for the chain to appear loose when the door is closed. If the chain returns to the position as shown below when the door is opened, the chain is adjusted properly. DO NOT retighten the chain. When performing maintenance, always PULL the emergency release to DISCONNECT the door from opener before adjusting the chain. Installing Cable and Chain. WARNING To prevent SERIOUS INJURY DO NOT connect power until instructed. Keep hands and fingers clear from sprocket during operation. Wear gloves when installing chain and cable.

Keep hands and fingers away from joints and possible sharp edges. Extend the line onto the header wall above the door spring. 2. Open the door to the highest point of travel. Mark a line on the header wall 2” 5cm above the highest point of travel. Note DO NOT install the header bracket over

drywall. In some installations, it may be necessary to install a 2 x4 across two wall studs to create a suitable location for the header bracket. If installing into masonry, use concrete anchors not provided. Wall Mounting As shown in Fig.2, place the header bracket on the vertical centerline in direction shown. Alternative Ceiling Mounting Ceiling mounting is suggested ONLY when clearance is minimal. Extend the vertical centerline onto the ceiling as shown in Fig.3. center the header bracket on the vertical mark, no more than 6" 15cm from the header wall. Mark and drill holes to fasten the header bracket securely to a structural support. **WARNING** To prevent **SERIOUS INJURY DO NOT** connect power until instructed. The header bracket **MUST** be **SECURELY** fastened to the structural support on the mounting wall or ceiling, otherwise the door may not reverse when required. **DO NOT** install the header bracket over drywall. Concrete anchors **MUST** be used when mounting the header bracket into masonry. **NEVER** try to loosen, move or adjust garage door springs, cables, pulleys, brackets, or hardware. Contact a qualified garage door service technician if your door binds, sticks or is unbalanced. An unbalanced door might not reverse when required. **CAUTION** To prevent **SERIOUS INJURY DO NOT** connect power until instructed. **REINFORCEMENT** is recommended for fiberglass, aluminum or lightweight steel garage doors **BEFORE** installing the door bracket. To mount the Door Bracket Note Some door reinforcement kits may provide direct attachment of the door arm to the reinforcement bracket. Note **DO NOT** use Self Threading Screws on a wood door. Mounting Opener to Ceiling.



<https://events.citeve.pt/chat-conversation/boss-looper-rc-3-manual>

Secure with a overhand knot. Fig. 1 Fig. 2 ! **WARNING** To prevent **SERIOUS INJURY** or **DEATH** from a falling garage door In case of power failure or door obstruction, **PULL EMERGENCY HANDLE** to release door from opener. When emergency release is in the released position, the door can be operated manually. To reconnect, flip the lever on the trolley towards opener, back to connect position, it will reconnect automatically upon pressing wall panel or remote control. **DO NOT** use emergency handle to pull the door open or closed. An Emergency release knob set too low may get caught by the vehicle and cause damage to the opener. Measure from the floor to the top of your vehicle and set the emergency release knob above this measurement. **1 0 0 W M A X** Please read

and understand the wiring instructions before connecting wires. 1. Remove the precut skin on the open end of wire from accessories. Wires MUST NOT be frayed. Each pair of terminals MUST be connected with one white wire and one striped wire non polarized from the SAME accessory as shown in Fig.2. 5. Check for proper connection by gently pulling on the wire. The wire should not come out of the terminal. Be careful not to damage the wires while securing the staples. ! WARNING To prevent SERIOUS INJURY or DEATH from electrocution Power MUST NOT be connected until instructed. NO exposed part of the wire should be visible outside of the terminal for proper connection. When properly connected and aligned, the emitter photo eye emits an invisible infra red light beam while the sensor photo eye monitors that beam. If the beam is obstructed during doorclosing, the entrapment protection will be triggered and the door will stop and reverse to the open position. The courtesy light will flash for 30 seconds indicating an obstruction. Installing The Photo Eye Safety System Wallmounting 1. Place the photo eyes facing each other on each side of the garage door.

<http://lescahiersdemarie.com/images/991-3.4-manual.pdf>



The push button is a wired, illuminated door control placed inside your garage. To install the Push Button 1. Inside your garage, install push button within sight of the door at a minimum height of 5 feet 1.5m off the ground. Ensure it is installed out of the reach of children and free from the moving parts of the door and hardware. 2. Securely fasten it to a solid surface with 1" screws. To prevent SERIOUS INJURY or DEATH from electrocution Power MUST NOT be connected until instructed. To prevent SERIOUS INJURY or DEATH from using the push button and a closing door Install the push button within sight of the door at a minimum height of 5 feet 1.5m above the floor. Make sure it is out of the reach of children and moving parts of door and hardware. NEVER permit children to access the push button or remote controls. Operate the door ONLY when it is adjusted properly with no obstructions present and is in clear sight. ALWAYS keep a moving door in sight until it's completely closed. NEVER cross the path of a moving door. Push Button Min. 5 feet 1.5m above floor From Push Button Connecting Push Button. See Accessories in Repair Parts section of this manual. The red photo eye will not light until it is aligned with the green eye. 2. When the photo eye system is properly aligned the green photo eye emitter will emit a steady green light and the red photo eye sensor will emit a steady red light. 3. If either of the photo eye lights are unsteady, flash or dim, check for an obstruction and carefully adjust the position of the photo eyes until they give a steady green light and steady red light. Note The path of the invisible light beam MUST NOT be obstructed. No part of the garage door or any hardware should interfere or block either sensor. ! Aligning the Photo Eye Safety System. WARNING To prevent SERIOUS INJURY or DEATH from electrocution or fire Power MUST be DISCONNECTED BEFORE proceeding with permanent wiring procedures.

<http://www.leszomni.com/images/990xa-gd55-manual.pdf>



Garage door opener in stallation and wiring M UST be in compliance with all local electrical and buildi ng codes. Make sure the opener is ALWAYS grounded. NEVER use an extension cord, 2wire adapter or modify the power plug in any way to make it fit the outlet. Ordinary Pow er Connection WARNING To prevent SERIOUS INJURY or DEATH from a clo sing garage door The photo eye safety system MUST be installed BEFORE conne cting power. The photo eye safety system MUST be properly con nected and aligned BEFORE operating the opener. NOTICE The opener will not close until the photo eyes are in stalled. Photo eyes are required by federal law to be installed on all openers. To Connect Power Plug the opener into a ground ed outlet ONLY. If there is no grounded outlet present, call a qualified e lectrician to replace the outlet. Use of a surge protector is highly recommended page 4. Permanent Wiring If Required by Local Code 1. Remove the enclosure by removing the 6 screws located on the sides and rear of the open er. 2. Cut the two cable pressure connectors connecting line black and neutral white wire from the power cord. 3. Remove the grounding screw connectin g the green wire. 4. Remove the power cord. 5. Group ne utral white wire s from power source with 2 white wires from light cable, and logi c board, and yello w wire from motor, inside the opener. Connect them with a wire nut. 6. Group line black wires from power so urce with another black wires from logic bo ard inside the opener. Conne ct them with a wire nut. 7. Secure the ground green or b are wire from the powe r source with a grounding screw. 8. Reinstall the enclosure. 9. Turn on powe r supply. If the wiring is properly connected, a “click” should be heard and the light will illuminate if a bulb is installed. If there is no response from the opener, che ck power source and wiring. BEFORE making any adjustment s, operate the door by using the large push button or remote. Ru n the opener through a complete cycl e.

If the door opens and close s completely without unintended reversing upon closing — NO adj ustment is necessary. If the door does not open or close at de sired positions, pro ceed with the instructions below to adjust the travel limits. Use a “flat head” screwdriver to make adju stments. One full turn of the screw is about 2” 5cm of actual travel. NOTE The opener m otor includes an aut omatic thermal protection system which will shut down the motor in an overheat situation. The thermal protector will reset itself once the motor cools down. Opening and closing the opener multiple times in a short period of time may cause the mo tor to overheat and shut down. If this happens, wait about 15 minutes for the motor to cool and retry operation. Setting OPEN UP Travel

Limit 1. CLOSE the garage door by using either the remote or large push button. 2. Adjust the OPEN limit screw. 3. OPEN garage door and check for proper adjustment. 4. Repeat steps 13 until the door opens to the desired position. When the door is in the open position, make sure there is enough clearance for your vehicles, and there is a minimum 2" 5cm gap between trolley and stop bolt. 5. Perform Safety Reverse Test on page 18. If the door does not open past 5 feet 1.5m, follow Force Adjustment on page 17 to adjust the open force. Setting CLOSE DOWN Travel Limit 1. OPEN the garage door by using either the remote or large push button. 2. Adjust the CLOSE limit screw. 3. CLOSE the garage door and check for proper adjustment. 4. Repeat steps 13 until door closes to the desired position. 5. Perform Safety Reverse Test on page 18. Travel Limit Adjustment. If the door reverses unintentionally during closing, check below symptoms 1. The photo eye system may be improperly connected, misaligned or obstructed The courtesy light will flash continuously for 30 seconds. Refer to Troubleshooting on P.22. 2. Binding door — disconnect the door from the opener by using the emergency release handle.

<http://www.abaco-engineering.it/wp-content/plugins/formcraft/file-upload/server/content/files/16286b5c0146da---cacti-graph-export-manual.pdf>

Open and close the door manually and check the following steps. 2.1 If the door is balanced, refer to Force Adjustment on Page 17 to adjust Close force. 2.2 If the door is unbalanced, binding or jammed, call a trained service person to adjust the door. The force adjustments regulate the amount of force required to open or close the door. 2. Force adjustment is applied only to compensate for the minor resistance caused by weather or other means. Note Force is preset at level 6 for both open and close adjustments. Weather conditions may also affect the operation of the door requiring further adjustments as needed. Note If the close force is set too light the opener will reverse the door during closing. If the open force is set too light the opener will stop the door during opening. Note There are 12 levels for open and close force settings. When either the maximum or minimum level is reached, the light will flash 6 times. Never adjust the force setting by more than 1 level 1 press at a time. Setting Force Setting Close Force 1. If the door completes a full close cycle without reversing, decrease the close force by 1 level at a time until the door reverses. Setting Open Force 1. If the door completes a full open cycle without stopping, decrease the amount of force by 1 level until the door stops during the opening. The close force is now properly adjusted. 2. During the "door open" cycle the opener will stop if the force required to open the door is exceeded. Force Adjustment ! WARNING To prevent SERIOUS INJURY or DEATH from improper force adjustment DO NOT adjust force to compensate for binding or sticking of the garage door. Call a qualified garage door service technician to make necessary adjustments in case of binding. DO NOT increase the force beyond minimum force required for closing the door. For safe operation, the force settings should always be set at the MINIMUM FORCE required to run the door.

<https://fincalarocia.com//ckfinder/userfiles/files/comodo-time-machine-user-manual.pdf>

If the door still does not reverse on the object, decrease the close force see Force Adjustment on page 17 and repeat the test. If the opener still fails the safety reverse test, call a qualified technician for door adjustment. Testing the Photo Eye Safety System 1. Open the door by using the large push button or remote 2. Make sure both photo eyes steadily emit the green and red indicator lights. If not, check alignment 3. Place an object under the door about 8" 20cm high by 12" 30cm wide the opener carton can be used, 4. The red indicator light on the sensor eye should be dimmed. 5. Keep the door in sight and use the large push button or remote to try to close the door. 6. The door should NOT move more than 1" 2.5cm and the courtesy light should flash for 30 seconds. Final Adjustments and Testing. NEVER cross the path of a moving door. To reduce risk of fire, explosion or electric shock DO NOT short circuit, recharge, disassemble or heat the battery. Replace with 23AE 12 volt batteries ONLY. Dispose of batteries properly. Visor Clip Holster Signal and Battery Indicator 23AE 12 Volt Alkaline Battery To Program Remotes 1. See Fig.2 to add a remote. Press the "LEARN"

button on the rear control panel of the opener. Retry programming the remote by repeating the steps above. Removing all Remotes To remove all remotes from memory, press and hold the "LEARN" button for 5 seconds. The courtesy light will flash 7 times indicating all remotes have been removed from memory. To replace the battery, remove the battery cover from the remote as shown in Fig 4. Replace with a 23AE 12 volt alkaline battery with polarity shown in Fig.4. Fig.1 Fig.2 Fig.4 This device complies FCC rules for HOME OR OFFICE USE. Operation is subject to the following two conditions 1 this device may not cause harmful interference, and 2 this device must accept any interference received, including interference that may cause undesired operation. x2 Fig.

3 LEARN 30 seconds NO ONE should cross the path of a moving door. To reduce risk of fire, explosion or electric shock DO NOT short circuit, recharge, disassemble or heat battery. Replace with 1.5 volt AAA batteries ONLY. Dispose of batteries properly. To Add Personal Codes 1. Press the "LEARN" button on the rear control panel, "OK" LED will glow and beep. If the code is entered incorrectly, correction can be made by pressing "ENTER" to reset and reenter code. When dark, "ENTER" may be pressed in advance to turn on back light. Mounting the Keyless Entry Keyless entry may be secured on door jamb face outside your garage. Locate keyless entry within sight of door at minimum height of 5 feet 1.5m, ensure it is away from reach of children and moving parts of door and hardware. Test the reception of the keyless entry before mounting. Change location for better reception if necessary. Use the mounting holes on the keyless entry as template to mark position on the mounting surface. To attach to a wooden surface use the screws provided. In case of a drywall surface, drill holes and use drywall anchors provided. Replacing Keyless Entry Battery When the battery of keyless entry is low, dimmed illumination is observed. To replace battery, remove the battery cover by loosening the screws underneath, and replace the battery with two 1.5 volt AAA batteries. WARNING To prevent SERIOUS INJURY or DEATH READ AND FOLLOW ALL INSTRUCTIONS AND WARNINGS IN THE OWNER'S MANUAL AND LABELS Keep remote and battery out of reach of children. NEVER permit children to access the wall panel or remotes. Operate the door ONLY when it is properly adjusted, and there are no obstructions and is in clear sight. ALWAYS keep a moving door in sight until completely closed. To Reconnect Trolley Pull the knob toward the opener so that the lever will flip up to the CONNECT position. Activation 22 Conduct safety reverse test after ANY adjustment.

The courtesy light flashes 5 times and the Opener does not start Opener motor overheat, please wait about 15 minutes and retry. The opener does not close the door and the green LED on the photo eyes flashes The photo eye safety system is misaligned or obstructed, refer to page 14 for proper alignment. The opener is working properly but the courtesy light does not turn on Replace light bulb A19 incandescent Max.100W. The courtesy light does not turn off Defective logic board. Schedule Maintenance Once a month Door balance test, refer to page 4. Safety reverse test, refer to page 18. Twice a year Check chain tension refer to page 6 for adjustment if necessary. Once a year Limit and force adjustment may be necessary due to weather conditions. Refer to pages 1617 for adjustment. Conduct safety reverse test after ANY adjustments. Lubricate door rollers, bearings and hinges. The opener is permanently lubricated, DO NOT lubricate or grease the opener, rail or door tracks. Maintenance With proof of purchase a defective product will be repaired free of charge. LIMITED WARRANTY ON PARTS FROM THE 91st DAY THROUGH 1 YEAR from the date of sale this product is warranted against defective parts. With proof of purchase a new part will be furnished to replace a defective one free of charge. Any costs for professional installation are not included. LIMITED WARRANTY ON MOTOR FROM THE 91st DAY THROUGH 4 YEARS from the date of sale the motor on this product is warranted against defects in material or workmanship. With proof of purchase a new motor will be furnished to replace a defective one free of charge. Any costs for professional installation are not included. This warranty also does not cover any problems caused by interference. LIMITATION ON LIABILITY Seller will not be liable for loss or damage to property or any incidental or consequential loss or expense from property damage directly or

indirectly to the use of this product.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. **DISCLAIMER OF IMPLIED WARRANTIES** Except for the motor, all implied warranties for this product, including but not limited to any implied warranties of merchantability and fitness for a particular purpose, are limited in duration to the 90 day and 91st day through 1 year limited warranty period set forth above. All implied warranties with respect to the motor are limited in duration to the 91st day through 4 year limited warranty period set forth above. No implied warranties will exist or apply after such periods. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you. This warranty applies only while this product is in use in the United States. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. Sears Brands Management Corporation, Hoffman Estates, IL 60179 26. Stuck Broken Call Now! We respect your privacy Easily overlooked, garage door openers are highly complex pieces of equipment, often containing dozens of intricate parts If you're looking for a smooth and quiet opener for a garage door with rooms located above the You can also choose a chain drive opener, which is perfect for garages that are unattached to the home. Up to a lifetime on the door sections on all the Sears Carriage House Collection and Sears three layer Sears warranties on labor and hardware is as good as, or better than, other garage door brands. This feature allows your garage door opener to work without power for up to 20 cycles to ensure you will be able This is a critical component to many homeowners who rely on the garage as the main entry point to the home. Can be operated with a mobile phone. His interest and guidance for the future care of the door was terrific. I thank him for his work and service.

P J Aleci It is not aesthetically pleasing. Also, the garage door opener that the serviceman fixed is no longer working. I'd like to have him return and fix it again. Thanks. We appreciate Sears making things right. Got a same day appointment. Service rep was great. My garage door and opener are functioning well again. Always happy with Sears service. The product is great the garage door opener is more quiet than expected. The service person installed it in half the time I expected. He did a great job of explaining things and then showing me what it could do. He finished installing the garage door opener in a timely fashion. Would definitely call the company for future service. He explained everything to me in detail. He cleaned up afterwards and took pride in his job. He took his time and didn't rush everything and did his job properly. If I purchase another door opener in the near future, I would like Jared to do the install if possible! Baron Spaulding. Colonel, U.S. Army Retired Both were very nice and knowledgeable. We love the new garage door. We chose the 3 panel, mahogany, with prairie insert windows and it looks fantastic on our house. We were amazed by how quiet the new opener is compared to our old one. Thank you! He was very friendly and explained the opening process, and cleaned up. Ricky was at my house last year to do the install of the opener and the rebuilt. I was glad to see him back for this routine check with my warranty. I am pleased with the services provided! Thanks so much! The door looked like new and the opener was upgraded. He went over everything with me so that I was comfortable with the upgrades. Thank you for the quick and professional service. Donna He is one of the best Technicians I have pleasure working with. Thanks. I need the serviceman come out and show me what I'm doing wrong. The garage door opener service manual doesn't have the answer. They explained the operation of the opener completely.

Thanks for sending a good installation team to my site. At this time we are pleased that so far the unit is operating as it should. Hopefully we hope the issue of the unit opening by itself at early morning hours is solved. And if this is so, we want to Thank all involved in bring a satisfactory solution to this nightmare. Knowledgeable about all the products and offered good advice. He was kind and funny as well. I was delighted and happy to pay for the door, opener and the service. I

would definitely recommend them. I wound up deciding to purchase a new opener and they returned to install it and new rollers the same day. Im happy with my decision. They fully explained the operation of the garage door opener and answered all my questions to my satisfaction. Thank you. We had confidence in his abilities from the start. He did a terrific job installing and explaining the product. We are highly satisfied with the garage door opener installation services. He also suggested additional items needing work on our garage door opener so that it performs much better. It also appears I ordered the wrong door openers, but he was able to input the correct code so that we can use them. We were very satisfied with all of his services. They installed the garage door opener promptly and did a great job. Kolev gave me some tips on how to use the garage door opener and answered all of the questions that I had. Overall, fantastic job and I will continue to use Sears Home Services in the future. I told him and now I am telling you. Give him a raise or at least a bonus. Thank you for sending him for my install. The service person who installed the new door opener was very efficient and helpful. He worked in the pouring rain to install our new garage door opener and we are very thankful. This is the first time I had to pay for a remote. Several have been replaced over the years. The technician contacted He installed the new opener and took away the nonworking old opener.

<http://www.jfvtransports.com/home/content/boss-looper-rc-3-manual>